

GASTROBACK®

VITAL MIXER

OPERATING INSTRUCTIONS



Art.-No. 60999 »Vital Mixer«

Read all provided instructions before first usage!
Model and attachments are subject to change
For household use only!




TABLE OF CONTENTS

| | |
|---|----|
| Important Safeguards | 25 |
| Safeguards for Daily Operation | 25 |
| Movable and sharp-edged parts – risk of injury | 30 |
| Important Safeguards for all Electrical Appliances | 31 |
| Technical Specifications | 32 |
| Knowing your Vital Mixer | 33 |
| Preparation | 34 |
| Before first use | 34 |
| Assembling the Blender Jug | 34 |
| Inserting the Blender Jug | 34 |
| Operation | 34 |
| General information | 34 |
| Tips for Preparation | 35 |
| Selecting the Speed Levels | 35 |
| Working with the Vital Mixer | 36 |
| Care and Cleaning | 38 |
| Cleaning the Blender Jug | 38 |
| Disassembling the Blender Jug and Removing Stubborn Residue | 39 |
| Cleaning the Motor Block | 39 |
| Storage | 40 |
| Troubleshooting | 40 |
| Notes for Disposal | 42 |
| Information and Service | 42 |
| Warranty | 43 |



IMPORTANT SAFEGUARDS

Save the instructions for further reference. Do not attempt to use this appliance for any other than the intended use, described in these instructions. Any other use, especially misuse, can cause severe injury or damage by electric shock, fire or moving mechanical parts. This instruction is an essential part of the appliance. When passing on the appliance to a third person, ensure to include these instructions.

Never leave the appliance unattended when in operational mode. Any operation, repair and technical maintenance of the appliance or any part of it other than described in these instructions may only be performed at an authorised service centre. Please contact your vendor.



SAFEGUARDS FOR DAILY OPERATION

Important: It is recommended that, this product should not exceed 1 minute in operation and allow 1 minute break in between each use.

- The appliance is designed for normal household quantities. Do not operate or store the appliance outdoors or in damp or wet areas.
- Do not attempt to operate the appliance using any parts or accessories not recommended by the manufacturer (i.e. blade, sealing ring). Do not operate the appliance, when the appliance or any part of it is likely to be damaged, to avoid risk of fire, electric shock or any other damage or injury to persons. Do not attempt to open the motor housing or to repair the power cord. Check the entire appliance regularly for proper operation. The appliance is likely to be damaged if the appliance was subject to inadmissible strain (i.e. overheating, mechanical, or electric shock) or if there are any cracks, excessively frayed parts, distortions or the motor stalls or gets stuck. In this case, immediately unplug the appliance and return the entire appliance (including all parts and accessories) to an authorised service centre for examination and repair.
- Do not lift, pull or carry the appliance by the power cord. To move or operate the appliance, always grasp the motor block.
- Close supervision is necessary when the appliance is used near young children. Do not let young children play with any parts of

the appliance or the packaging. The blade is extremely sharp. The appliance is not intended for use by children or infirm persons without supervision. Take care that no one will pull the appliance by the power cord, especially when young children are near.

- Always place the appliance on a clean, dry and stable surface where it is protected from inadmissible strain (i.e. mechanical or electric shock, overheating, frost, moisture) and where young children cannot reach it.

⚠ WARNING: To avoid injury to persons and damage, always turn the appliance ›off‹, wait for the motor to stop completely and unplug the appliance, immediately after operation and before assembling/disassembling or cleaning the appliance. Never use force operating, assembling or disassembling the appliance.

⚠ WARNING: The blades are very sharp. Pay attention when handling these parts. Only touch the blade unit housing when handling the blades. Handle with care when cleaning.

Note:

Ensure the appliance is properly assembled and the blade is properly attached before connecting the plug into the power outlet. Never turn the appliance on without the lid or the barlot. Never turn the appliance on without the blender jug properly placed on the motor block. Never place only the holder or the blade on the motor block. Never touch the drive gear when the plug is connected to the power outlet.

⚠ WARNING: If the blade is mounted in the blender jug, the blender jug is positioned on the motor block, and the plug is connected to the power outlet, do not insert your fingers, a wooden or plastic spoon or similar cooking utensils or foreign substances in the blender jug. Always take the blender jug off the motor block before pushing the food down with a spoon.

⚠ WARNING: Never combine the blender jug and the holder without the blade. Without the blade the bottom of the blender jug is open. Liquids could spill and might damage the motor block.

Without the blender jug, the appliance will not operate.

Important: Ensure the blender jug is locked securely onto the motor block and that you cannot knock the appliance over during operation. The motor will not start before the plug is plugged into the power outlet, the blender jug is securely locked onto the motor block and the appliance is switched ›On‹.

- As a safety feature, the appliance should shut off after operating for 1 minute. If you want to operate again, wait 1 minute and then continue.

⚠ WARNING: Do not overfill the blender jug. If necessary, take some food out of the blender jug, using a wooden or plastic spoon, before starting the appliance again.

⚠ WARNING: Do not operate the appliance when the blender jug has a crack or any part of it is likely to be damaged. The appliance is likely to be damaged if the appliance was subject to inadmissible strain (i.e. overheating, mechanical, or electric shock) or if there are any cracks, excessively frayed parts, distortions or the motor stalls or gets stuck. In this case, immediately unplug the appliance and return the entire appliance (including all parts and accessories) to an authorised service centre for examination and repair.

⚠ WARNING: Do not fill ingredients into the blender jug which exceed a temperature of 60 degrees. After processing ice cubes slowly heat up the blender jug before processing hot ingredients. Otherwise the blender jug will crack or get damaged. Use gloves processing hot liquids and do not fill the blender jug up too high. Ensure not to burn yourself on the blender jug, overrunning, and spurt out or hot steam.

Never place anything other than food and liquids in the blender whilst the motor is running.

⚠ WARNING: Do not place blender in the freezer with food or liquids. This will freeze and damage the blade assembly housing, blender jug and motor.

⚠ CAUTION: Do not place the appliance in an automatic dishwasher.

Attention: The circular plastic surround attached to the base of the blender jug is not removable! Same with the plastic surround attached to the blades.

Operate the appliance on a well accessible, stable, level, dry, and suitable large surface. Do not place the appliance or any part of it on or near hot surfaces (heater, gas burner, grill, or oven). Do not place the appliance near the edge of the table or counter or on inclined or wet surfaces or where it can fall. Keep the entire appliance away from direct sunlight and sharp edges. Ensure the blender jug is locked securely onto the motor block and that you cannot knock the appliance over during operation to avoid personal injury.

- Never leave the appliance unattended when the plug is connected to the power outlet. Always immediately turn the appliance off, wait for the motor to stop completely, and then unplug the appliance, if the appliance is not in use (even for a short break) and before assembling, disassembling or cleaning. Never leave the appliance unattended when in operational mode.
- Do not leave any food dry on the surfaces of the appliance. Do not immerse the motor housing or power cord in water or any other liquid. Do not pour or drip any liquids on the motor housing or power cord. When liquids are spilled on the motor housing, immediately unplug the appliance and dry the motor housing to avoid risk of electric shock or fire. Do not attempt to operate the appliance, when liquids are on or in the motor housing.
- Do not place the motor block in an automatic dishwasher!

- To avoid damage, do not use any abrasive cleaners, corrosive chemicals (i.e. disinfectants, bleach) or cleaning pads for operation or cleaning. Do not use any hard or sharp utensils for operation or cleaning. Always handle the entire appliance and all parts of it with care and without violence.

⚠ WARNING: The blades are very sharp. Pay attention when handling the blades. Only touch the blades on the blade assembly and handle with care when cleaning.

Do not use the appliance if it is damaged or parts of the appliance are damaged. Do not use the appliance if it does not function properly or if it was excessively loaded. The appliance is likely damaged if the appliance or parts of the appliance show cracks, exorbitant wearing down, alterations or leaks. It is also likely damaged if the drive wheel of the motor block moves slowly. Take the appliance for technical maintenance and repair to an authorised specialised reparation shop.

⚠ WARNING: Do not overfill the blender jug. If necessary, take some food out of the blender jug, using a wooden or plastic spoon, before starting the appliance again.

⚠ WARNING: Do not fill ingredients into the blender jug which exceed a temperature of 60 degrees. After processing ice cubes slowly heat up the blender jug before processing hot ingredients. Otherwise the blender jug will crack or get damaged. Use gloves processing hot liquids and do not fill the blender jug up too high. Ensure not to burn yourself on the blender jug, on overrunning, spurt out or hot steam. Touch the handle only for lifting the blender jug.

The appliance is for household use only.



MOVABLE AND SHARP-EDGED PARTS – RISK OF INJURY

- Always turn the appliance off (all buttons are deactivated), wait for the motor to stop moving and then pull the plug before taking the blender jug off the motor block or taking off the lid. It could take about 3 seconds until the motor has completely stopped. Never leave the appliance on when not in use.
- Never put your hands, wooden spoons or other foreign substance (such as hair, cloth, brush, towels) into the blender jug when the motor is running or the appliance is connected to the power outlet. Always take the blender jug off the motor block first before you push down the food with a spoon or add new ingredients.

⚠ WARNING: The blades are very sharp. Pay attention when handling the parts. Only touch the blade assembly housing when handling the blades. Handle with care when cleaning. Only store the appliance completely assembled. This way the blades will be out of reach.

Note:

Ensure the appliance is properly assembled and that the blade is properly attached before putting the plug into the power outlet. Never turn the appliance on without the lid or the refill lid. Never place only the holder or the blade only on the motor block. Never touch the drive gear when the plug is connected to the power outlet.

- Always keep one hand on the lid while processing. Using solid ingredients (such as hard fruits or vegetable), overloading the blender jug or processing with a slow speed, the motor could stuck, stall or run very slow. In this case turn the appliance off to avoid overheating (see >Trouble shooting<).

⚠ WARNING: If the blade is mounted in the blender jug, the blender jug is positioned on the motor block, and the plug is connected to the power outlet, do not insert your fingers, a wooden or plastic spoon or similar cooking utensils or foreign substances in the blender jug. Always take the blender jug off the motor block before pushing the food down with a spoon.



IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Always operate the appliance near a suitable wall power outlet and connect the appliance directly to the power outlet. Do not use any extension cords or a multiple desk outlet.
- Ensure that the voltage rating of your mains power supply corresponds to the voltage requirements of the appliance (230V, 50/60Hz, AC). Always connect the appliance directly to a mains power supply wall socket with protective conductor (earth/ground) connected properly. The installation of a residual current safety switch with a maximum rated residual operating current of 30mA in the supplying electrical circuit is strongly recommended. If in doubt, contact your local electrician for further information.
- Do not leave the appliance unattended when connected to the power supply. Always turn the appliance off (all buttons are deactivated) and immediately unplug the appliance after operation and if it is not in use (even for a short break) and before cleaning and/or assembling or disassembling. Always grasp the plug to disconnect the appliance from the power outlet.
- Always handle the power cord with care. Do not pull or strain the power cord. The power cord may never be knotted or squeezed. Do not let the power cord hang over the edge of the table or counter. Take care not to entangle in the power cord. Do not touch the appliance with wet hands to avoid risk of electric shock. Do not touch the appliance, if it is damp or wet or is touching wet surfaces while connected to the mains power supply. In this case, immediately unplug the appliance and dry the appliance (see ›Care and Cleaning‹).
- Ensure that the holder is leak-proof before putting the blender jug on the motor block. Always wipe off spilled liquids immediately. Do not immerse the motor or power cord in any liquids or spill any liquids on it or place the motor on wet surfaces. Never let any liquids run into the motor block or underneath it to avoid electric shock. There are louvres underneath the motor block. Ensure that no water can run into the louvre. When liquids are spilled on the motor housing, immediately unplug the appliance and dry the motor housing to avoid risk of

electric shock or fire. Do not attempt to operate the appliance, when liquids are on or in the motor housing.

TECHNICAL SPECIFICATIONS

| | |
|------------------------------|---|
| Model: | Art. No.: 60999 Vital Mixer |
| Power supply: | 230V, 50/60 Hz |
| Power consumption: | 850 W |
| Length of power cord: | approx. 100 cm |
| Weight: | approx. 2,9 kg |
| Dimensions: | approx. 175 x 185 x 395 mm (diameter x depth x height) |
| Capacity, glass jug: | 1.5 litre |
| Revolutions: | 18,000 - 21,000 per minute |
| Certification: |  |

These specifications may change without notice.

KNOWING YOUR VITAL MIXER



PREPARATION

BEFORE FIRST USE

Before first use and after prolonged storage period, clean the mixing jug in warm soapy water and then dry thoroughly (see: ›Care and Cleaning‹).

ASSEMBLING THE BLENDER JUG

1. Put the sealing ring on the inner edge of the blade unit.
2. Put the blade unit with sealing ring into the cup base.
3. Mount the cup base under the base of the blender jug and turn the cup base clockwise until it is fixed.
4. Mount the cup with the beaker onto the blender jug.
5. Place the beaker into the lid and close the blender jug with the lid.

INSERTING THE BLENDER JUG

1. Make sure that the blender is switched off (Switch in the ›0‹ setting).
2. Place the blender jug on the motor base. The mixer operates only with mounted blender jug. If you remove it during operation the mixer stops automatically.

OPERATION

GENERAL INFORMATION

Important: It is recommended that, this product should not exceed 1 minute in operation and allow 1 minute break in between each use.

Keep the workplace during work clean and dry. If necessary, wipe off splashes or spilled liquids with a dry cloth.

⚠ WARNING: Never place the motor base on wet underlayments or towels. Never let fluids run under or onto the motor base. If liquids have entered into the motor base, then immediately pull the power plug from the outlet, and have the appliance checked at a specialised service centre.

⚠ WARNING: Never put your hands or foreign objects (e.g. cooking cutlery) into the blender jug, when the blender jug is mounted on the motor base. Always switch to >0< (switch position: >0</AUS/OFF), wait until the blades stand still and then remove the blender jug from the motor base before removing the lid to check the content or pushing down the food in the blender jug. Use only cooking utensils made of wood, rubber or plastic. Apply no violence, if you push the food down the blender jug or dissolve ingredients that have become wedged in the blade. Your Vital Mixer cannot replace all your kitchen appliances. You cannot use it to mash potatoes, to beat eggs for a meringue or to prepare minced or juiced fruits or vegetables.

Important: Do not let food residue to dry in the blender jug of your appliance. Clean the appliance immediately after operation (see >Care and Cleaning<).

TIPS FOR PREPARATION

Always place liquid ingredients first in the Vital Mixer, if it is not otherwise specified in the recipe.

Cut solid foods (vegetables, fruits, cheeses, cooked meats, fish and seafood) in about 2 cm pieces. Do not overload the motor with too hard or too large ingredients. Turn the appliance off (ON/OFF-switch position >0< (AUS/OFF) when the motor gets stuck to avoid overheating (see >Trouble Shooting<).

Process the ingredients just a few seconds. It is better to consider the quality of the product in between, as to obtain a too fine, possibly mushy product.

With the two speeds and pulse function (switch position: >P<) you can prepare easily, versatile and quickly a variety of dishes.

SELECTING THE SPEED LEVELS

Turn the ON/OFF-switch easily to the desired speed level. The appropriate speed level is determined by the textures of the ingredients. To use the pulse function (position >P<) turn and hold the switch in position until the ingredients have reached the desired consistency.

| Speed Level | Switch Position | Function, Examples | Use |
|-----------------|-----------------|--|---|
| Pulse operation | PULSE-switch P | ice crushing & short, powerful impulse movements; Creaming butter/margarine | Crushing Ice: place 1 to 12 ice cubes in the blender jug and hold the switch at position P until the ice cubes have the desired size. |
| Slow | 1 | Puree; Prepare baby food | Cook food, let it cool and place with sufficient liquid into the blender jug. |
| | | Foaming; for whipped cream | Add sugar or flavorings according to taste. |
| | | Mixing; Stirring cream soups | Insert liquid first, then the other ingredients. |
| Quick | 2 | Whisking; for fruit dishes | Insert fresh fruit with yogurt, cream or sour milk. |
| | | juicing; for juice / puree from fresh fruits | Cut fresh fruit into 2 cm pieces and insert into the blender jug. |

WORKING WITH THE VITAL MIXER

⚠ WARNING: Always remove the blender jug from the motor base before opening the lid or checking the contents.

1. Place the ingredients in the blender jug.

Important: Pre-cooked ingredients should cool down before processing. If possible fill in the liquid ingredients first. Cut solid ingredients before placing into the blender jug into 2 cm pieces. Do not fill the blender jug too full. Otherwise, the content may overflow or spray out and the engine could get stuck.

2. Place the lid on the blender jar and press down firmly. Close the central opening of the lid with the transparent beaker. The has beaker two small guide pins that fit into the slots on the cover on both sides. Slide the beaker into the lid all the way down and turn it clockwise to lock.

⚠ WARNING: While the appliance is operating never remove the blender jug, remove the lid or insert wooden spoon or other foreign objects into the blender jug. Be sure to turn ON/OFF-switch to position 0 to turn off the appliance and wait until the motor has come to a complete stop. Then take down the blender jug from the motor base, before reaching into the blender jug or work with cooking utensils and similar objects in the blender jug.

⚠ WARNING: If you process hot ingredients, please make sure not to burn yourself on the blender jug or lid, or scald on steam or spraying liquids. Place perhaps a kitchen towel over the lid to protect from splashes and steam.

Important: The motor will only operate when the blender jug is properly installed.

3. Keep one hand on the lid and turn the appliance on using the ON/OFF-switch. Be sure to select the desired speed level. The motor starts to work.

⚠ ATTENTION: If the motor ceases to operate unintentionally or is unusually slow, immediately turn the ON/OFF-switch to position ›0‹. Otherwise, the motor may overheat. Pay attention to the section ›Trouble Shooting‹.

Note:

If you have turned on the pulse function, the motor runs as long as you hold the switch.

4. After a few seconds turn the ON/OFF-switch to position ›0‹ (OFF) to turn off the appliance.
5. Once the blades have come to a stop, grasp the blender jug by the handle and remove the jug from the motor base. Afterwards you can remove the lid to check the product or push solid or viscous ingredients with a wooden or plastic spoon down gently.

If you wish to add other ingredients, use the beaker from the lid. To do this, turn the beaker first anti-clock-wise and then pull it up and out. Put the ingredients through the resulting hole and put the beaker afterwards back on.

You may possibly want to run the appliance once more for a few seconds until the product has the desired texture. Return the blender jug onto the motor base. You can then turn on the appliance again.

6. When the product has the desired consistency, turn the appliance off (ON/OFF-switch to position ›0‹) and remove the blender jug from the appliance. Then remove the lid from the blender jug. Flowable products - from drink to viscous dough - you can pour from the blender jug. Then you can clean the blender jug immediately according to the instructions.

Important: Do not leave to dry any food residues on the parts of the appliance. Clean the equipment immediately after each use in accordance with the instructions ›Care and cleaning‹.

CARE AND CLEANING

⚠ WARNING: Wear appropriate gloves when working with hot liquids. Be careful not to burn yourself on the blender jug, scald spouted or overflowing liquids or steam.

⚠ ATTENTION: Never use hard or sharp-edged objects, caustic cleaning products (disinfectants), scouring aids (scourer), or abrasives to clean the appliance or the any accessories. Do not apply any violence when cleaning the knife insert so as not to bend the blades and not to damage the mounting. Never clean the appliance or any components of it in the dishwasher.

CLEANING THE BLENDER JUG

⚠ WARNING: The blades of the knife insert are sharp. Treat the blades carefully and without violence, so as not to cut you and not to damage the blades.

1. Empty the blender jug completely and rinse loosely adhering food with clean water.
2. Then fill hot detergent solution into the blender jug. The blades should be covered with the solution. Seal the jug with the lid, turn the appliance on (switch position: >1<) and let it work for a few seconds.
3. Switch the appliance off (ON/OFF-switch position >0< (AUS/OFF). Wait until the blades have come to a stop, and remove the blender jug from the motor base.
4. Unplug the power plug from the outlet.
5. Remove the lid from the blender jar and pour out the detergent solution. Remove residue on the walls of the blender jar. You can easily remove clinging residue with a plastic cleaning.

⚠ WARNING: Use extreme caution when working in the area of the blades; be careful not to cut on the sharp blades and not to damage the blades.

Important: In most cases, the blender jug will already be hygienically clean. However, should food residues still are adhering to the knives, then disassemble the bottom of the jug and clean the components individually.

6. Rinse the lid and the beaker in warm detergent solution.
7. Rinse the blender jug, the lid and the beaker afterwards with clean water, dry the parts with a dish towel gently and let it dry out of the reach of small children at the air.

DISASSEMBLING THE BLENDER JUG AND REMOVING STUBBORN RESIDUE

⚠ WARNING: The blades of the knife are very sharp. Treat the blades carefully and without violence, be careful not to cut on the sharp blades and not to damage the blades.

8. Keep the blender jug over a sufficiently large bowl, turn the mount to the left and remove knives and the sealing ring downwards.
9. Rinse all parts of the mixing jar in warm detergent solution. Soak the stubborn food residues on the parts for a few minutes and then remove these with a small plastic brush or sponge. While doing so be careful not to cut on the sharp blades.
10. Rinse the parts of the blender jug with clear water and dry the parts afterwards with a clean cloth gently. Let the parts (especially blades and bottom of the jug) dry in a protected and inaccessible to small children area at the air. Place the parts back together after drying (see ›Assembling the Blender Jug‹).


CLEANING THE MOTOR BLOCK

⚠ WARNING: Always unplug the power cord before cleaning the motor base. Never pour water or other liquids on the motor base, run into the motor base or under the motor base. Never immerse the motor base in liquids or place on wet or damp surfaces. Wipe away spilled liquids immediately. At the bottom of the motor base are vents. Please ensure that no water can run or drip into these openings.

1. Unplug the power plug from the outlet.
2. Then wipe the motor base with a damp, not dripping cloth. Make sure to avoid damaging the drive wheel and bearing of the drive wheel in the centre of the socket. Never poke with fixed or hard objects in the mount of the motor base. Use a soft brush if necessary to clean the mount. If moisture gets into the mount of the motor base, clean and dry the mount very carefully and thoroughly.
3. Dry the appliance thoroughly. The entire motor base must be completely dry before you reassemble the appliance and use.

STORAGE

Assemble the blender jug for storage completely and correctly to avoid injury from the blade and loss of parts. Place the blender jug onto the socket of the motor base. In this way, the sealing ring, the knives and the drive wheel are protected best against dirt and damage.


 **WARNING:** Never place the bottom of the jug or the knives without the blender jug on the motor base.

Important: Do not let the power cord slide across the floor and make sure that the power cord does not hang or can be caught.

Store the appliance in a clean and dry place, where it is protected from excessive loads (impact, shock, dirt, humidity) and inaccessible to small children. Do not place hard or heavy objects on the appliance. The storage location should be protected from frost and not be warmer than 40 °C.

TROUBLESHOOTING

The Vital Mixer is reliable and robust and will work smoothly usually when operated properly. However, should a problem occur, you will be able quite easily to eliminate this in most cases. The following error table is intended to assist.

 **WARNING:** Do not attempt to use this appliance for any other than the intended use, described in these instructions. Maintenance and repair of the appliance must be performed only by an authorized service centre. Do not use the appliance when it is probably damaged or is not working as expected.

| Problem | Solution |
|---|---|
| The motor stops during operation or can not be turned on again. | Switch off the appliance immediately (turn the ON/OFF switch to position >0<), when the motor stops unexpectedly or is stuck to prevent overheating. Then, check the following points: The motor operates only when the blender jug is properly and fully assembled. Make sure that the blender jug is properly assembled. Remove the blender jug from the motor base and clear gently with a wooden or plastic spoon stuck pieces of food on the blade. Apply no violence not to damage the blades. Shred hard ingredients outside of the mixer. Remove a part of the ingredients from the blender jug and then try again with a higher speed level. Attention: Do not overload the motor of the appliance with too hard or too large ingredients. Do not over load the blender jug. Process solid ingredients possibly in several steps. |

| Problem | Solution |
|--|---|
| The bottom of the blender jug loosens up during operation; liquid escapes. | <p>Switch off the appliance immediately (turn the ON/OFF switch to position >0<) and unplug the power plug from the outlet. Empty the blender jug immediately. Clean and dry the motor base. If liquids have been spilled into the air vents at the bottom of the motor base, and have the appliance checked in a specialised service centre.</p> <p>Make sure that the blender jug is correct and fully assembled according to the instructions >Assembling the Blender Jug<.</p> <p>TIP: Before filling in the ingredients check the tightness of the mixing jar with some water.</p> |
| You fail to seal the blender jug; liquid escapes at the bottom of the blender jar. | <p>Schalten Sie sofort auf >0< (Schalterpositon: AUS) und ziehen Sie den Netzstecker. Leeren Sie den Mischkrug sofort aus. Reinigen und trocknen Sie den Motorsockel. Wenn Flüssigkeiten in die Luftschlitzte am Boden des Motorsockels eingedrungen sind, dann lassen Sie das Gerät in einer Fachwerkstatt überprüfen.</p> <p>Vergewissern Sie sich, dass der Mischkrug nach der Anleitung (Glasbehälter zusammensetzen) richtig und vollständig zusammengesetzt ist.</p> <p>TIPP: Prüfen Sie vor dem Einfüllen der Zutaten die Dichtigkeit des Mischkrugs mit etwas Wasser. Ziehen Sie gegebenenfalls den Krugboden etwas fester an. Überdrehen Sie dabei nicht das Gewinde am Krugboden. Wenn der Krugboden trotzdem undicht ist, dann beachten Sie die Hinweise im nächsten Punkt.</p> |
| The motor starts stuttering or is too slow. | <p>Turn to the higher speed level. Pour possibly some of the ingredients from the blender jug. Pound solid ingredients outside of the mixer.</p> |
| The appliance does not turn on. | <p>Check if the blender jug is properly assembled. If the security ring has been applied in the wrong direction, the appliance cannot be switched on. When the blender jug is assembled correctly, it engages easily onto the motor base.</p> |

NOTES FOR DISPOSAL



Dispose of the appliance and packaging must be effected in accordance with the corresponding local regulations and requirements for electrical appliances and packaging. Please contact your local disposal company.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills, dumps, or refuse incineration, hazardous substances can leak into the groundwater or can be emitted into air, thus getting into the food chain, and damaging your health and well-being as well as poisoning flora and fauna. When replacing old appliances with new once, the vendor is legally obligated to take back your old appliance for disposal at least for free of charge.

INFORMATION AND SERVICE

Please check www.gastroback.co.uk for further information.

For technical support, please contact Gastroback Customer Care Center by phone: +49 (0)4165/22 25-0 or e-mail info@gastroback.co.uk.

Please refer to our home page for a copy of these operating instructions in pdf format.

WARRANTY

We guarantee that all our products are free of defects at the time of purchase. Any demonstrable manufacturing or material defects will be to the exclusion of any further claim and within 2 years after purchasing the appliance free of charge repaired or substituted. There is no Warranty claim of the purchaser if the damage or defect of the appliance is caused by inappropriate treatment, over loading or installation mistakes. The Warranty claim expires if there is any technical interference of a third party without a written agreement. The purchaser has to present the sales slip in assertion-of-claim and has to bear all charges of costs and risk of the transport.

Note

Customers from Germany and Austria: For repair and service, please send Gastroback products to the following address: Gastroback GmbH, Gewerbestr. 20, D-21279 Hollenstedt, Germany.

Customers from other countries: Please contact your dealer.

Please agree that we cannot bear the charge of receipt. Submission of appliances: Please ensure packing the appliance ready for shipment without accessories. Add the sales slip and a short fault description. The processing time after receipt of the defective appliance will be approx. 2 weeks; we will inform you automatically. After the warranty period, please send defective appliances to the given address. You will get a free quotation and, thereafter, can decide, whether we shall repair the appliance to the costs possibly accrued, send back the defective appliance for free of charge, or dispose of the appliance for free of charge.

The appliance is intended for household use only and NOT suited for commercial usage. Do not attempt to use this appliance in any other way or for any other purpose than the intended use, described in these instructions. Any other use is regarded as unintended use or misuse, and can cause severe injuries or damage. There is no warranty claim of the purchaser if any injuries or damages are caused by unintended use.

GASTROBACK GmbH

Gewerbestraße 20 . 21279 Hollenstedt / Germany
Telefon +49(0)41 65 / 22 25-0 . Telefax +49(0)41 65 / 22 25-29
info@gastroback.co.uk . www.gastroback.co.uk

20210125